

# マグネット基台取扱説明書

## 各機種共通

**DIAMOND**  
ANTENNA

このたびはダイヤモンド基台をお買い求めいただきまして誠にありがとうございました。ご使用の前に、この取扱説明書をよくお読みの上、正しくお使いください。お読みになったあとは大切に保存してください。

### ●ご使用の前に

マグネット基台は、磁石の力で車に固定する簡易的なアンテナ基台です。脱落による事故を防ぐために、以下の注意事項をお守りください。

- ①指定されたアンテナ以外は取り付けしないでください。
- ②木の枝などの障害物があるときはアンテナを取り外してください。
- ③高速道路では100Km/h以下のスピードで走ってください。また、向かい風の時にはスピードを下げるか、アンテナを取り外してください。
- ④マグネット基台と車体の間に物を挟まないでください。
- ⑤曲面や凹凸のあるところはさけ、平坦なところに設置してください。
- ⑥設置するところの汚れは、あらかじめきれいに拭き取ってください。
- ⑦鉄製のところ以外では使用できません(吸盤付きも含みます)。

### ●設置と配線

- ①同軸ケーブルを引き込んだ隙間から、車内に雨水が入ることがあるので注意してください。
- ②マグネット基台の脱着は、必ず取り付けられたアンテナの下部を持って行ってください。同軸ケーブルを引っ張ると車に傷が付いたり故障の原因になります。

### ●ご注意

- ①マグネット基台は磁石で引き寄せた鉄粉が原因でサビが発生したり、車体に傷が付くことがあります。定期的に拭き取ってください。
- ・シンナーやベンジンなどでは拭かないでください。
  - ・汚れのひどいときは、水で薄めた中性洗剤をご使用ください。

- ②アンテナを取り外したときには、付属の防水キャップをコネクタ一部に付けてください。

### ●指定アンテナ

以下の条件のステンレス製ホイップアンテナ以外は使用できません。

型 名	全 長	重 量
K701(吸盤付き)	1.5m以下	350g以下
K702(吸盤付き)	1.5m以下	350g以下
K707(吸盤付き)	1.0m以下	150g以下
SPM	1.2m以下	350g以下
DPK-4NM	1.2m以下	350g以下
MR2	1.1m以下	250g以下
MRK	1.0m以下	150g以下
MR5A	1.0m以下	150g以下

- ・お買い上げいただきました製品は、厳重な品質管理のもとに生産されておりますが、万一運搬中の事故などによる破損がありましたら、取扱店にお申し付けください。
- ・この製品の仕様及び外観は、改良のため予告なく変更することがありますのでご了承ください。

2005年4月

# Strong Magnet Antenna Base

## Operation Instructions

To use this magnet antenna base properly, read this instruction thoroughly before using it. Keep this manual carefully at hand for later use.

②When removing the antenna, cover the connector parts with the attached water proof cap.

### ● Before Using

Strong magnet antenna base is a temporary magnet antenna base fixed the antenna temporarily on a car body.

To prevent any accident, pay attentions to the following instructions.

- ① Don't use the antenna exceeding the specified length and weight.
- ② Remove the antenna when there are obstacles such as branches.
- ③ Drive a car at less than 100km/h. When a head wind, speed down or remove the antenna.
- ④ Don't insert anything between the magnet antenna base and the car body.
- ⑤ Don't install the magnet antenna base on the curved places.
- ⑥ Clean up the place where are installed.
- ⑦ Install the magnet antenna base only on the iron surface. (All models)

### ● Required antennas

Please use the antenna (stainless steel) with FOS covered by the following the conditions.

Model No.	Length	Weight
K701 (with suction cap)	Less than 1.5m	Less than 350g
K702 (with suction cap)	Less than 1.5m	Less than 350g
K707 (with suction cap)	Less than 1.0m	Less than 150g
SPM	Less than 1.2m	Less than 350g
DPK-4NM	Less than 1.2m	Less than 350g
MR2	Less than 1.1m	Less than 250g
MRK	Less than 1.0m	Less than 150g
MR5A	Less than 1.0m	Less than 150g

### ● Installation and Wiring

- ① Be careful not to introduce rainwater into the car through the coaxial cable.
- ② When installing and detaching the magnet antenna base, be sure to hold the lower part of the antenna. Pulling the coaxial cable may be caused to damage the car body.

Though these products purchased are manufactured under strict quality control, if a damage is caused by transporting, ask your dealer promptly.

Design and specifications of these products will be changed for future improvement without advance notice.

### ● Note

- ① Iron powder gathered by the magnet in the base causes rust on the car body and damages the body.
  - Don't wipe it off with thinner and benzine.
  - If it becomes too dirty, wash it with neutral detergent.

DIAMOND ANTENNA CORPORATION

Miyata Building, No. 15-1, 1-chome Sugamo, Toshima-ku Tokyo, Japan 170-0002 TEL.03-3947-1411 FAX.03-3944-2981

Home Page <http://www.diamond-ant.co.jp>